




POT FEEDER & FILTER HOUSING SCHEMATIC DIAGRAM

Pot Feeder # PF010380
Filter Housing # BP010001
Flow Indicator # IF010300



Instructions for adding treatment to system using Pot Feeder

1. Close Valves A and B. Open Valve C to de-pressurize pot feeder.
2. Remove pot feeder cap. When pot feeder has been completely drained, close Valve C.
3. Add required quantity of treatment solution to pot feeder.
4. Top up feeder with system water to prevent introduction of oxygen.
5. Replace cap and tighten securely.
6. Slowly open Valves A and B while checking system for leaks.